



GE Security

*466-1821 Rev D
March 2004*

www.GE-Security.com

**Part No:
60-874-95R**



Allegro

Installation Instructions

Notices

FCC Part 15 Information to the User

Changes or modifications not expressly approved by GE Security can void the user's authority to operate the equipment.

FCC Part 15 Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the affected equipment and the panel receiver to separate outlets, on different branch circuits.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: B4Z-785B-ALGRO

Patent Information

This product and the use of this product may be covered by one or more of the following patents: 5,805,063, 5,872,512, 5,942,981, 5,686,896, 5,686,855, 4,855,713. Except as expressly provided herein, the purchase of this product shall not constitute a license or otherwise provide a right to practice a method covered by any of the identified patents. GE Security hereby grants the purchaser of this product a limited non-exclusive license to practice the methods patented in the identified patents solely with products manufactured, sold or licensed by GE Interlogix. This license grant does not extend to the use of unlicensed third party products with this product.



GE Security

©2004 GE Security. *Allegro* and *Dialog* are trademarks of GE Security. *Toolbox* is a registered trademark of GE Security. All other trademarks are properties of their owners.

All rights reserved.

1275 Red Fox Road
Arden Hills, MN 55112
Technical Support: 800-777-2624

Contents

Special Installation Requirements **1**

UL Listed Systems.....	1
Basic System.....	1
Household Burglary Alarm System Unit (UL 1023).....	1
Household Fire Warning System (UL 985)	1
Digital Alarm Communicator System (UL 1635)	1
SIA System Requirements	1
SIA Setting Requirements	2
Central Station Reporting	2
UL-Canada Listed Systems	2
California State Fire Marshall Listed Systems	3

Planning the Installation **3**

Standard System	3
Panel.....	3
DTIM	3
Additional System Components	3

Installing the System **3**

Determine the Panel Location.....	4
Mounting the Panel.....	4
Connecting Detection Devices to Panel Zone Inputs	5
Connecting Intrusion	
Detection Devices	5
Connecting the AC Power Transformer	5
Connecting the Backup Battery Pack	5
Powering Up the Panel	6

Programming the Panel **6**

Panel Keypad Button Programming Functions	6
Clearing Memory	7
Learning the DTIM into the Panel.....	7

Installer Programming Menus **8**

Entering Installer Programming Mode	8
Account Menu (1st Tier).....	8
ACCOUNT (1st Tier)	8
Phones Menu (1st Tier).....	8
Phone 1 and Phone 2 (2nd Tier)	8
NUMBER 1 and NUMBER 2 (3rd Tier).....	9
FMT - CID (3rd Tier)	9
HIGH LVL (3rd Tier)	9
LOW LVL (3rd Tier).....	10
OPENINGS (3rd Tier)	10
CLOSINGS (3rd Tier)	10

BACKUP (3rd Tier).....	10
DIAL DLY (2nd Tier)	11
PRE-DIAL STRING (2nd Tier)	11
DTMF DIAL (2nd Tier)	11
Devices (1st Tier).....	11
ADD (2nd Tier)	12
DELETE (2nd Tier).....	13
REVIEW (2nd Tier).....	13
TEXT (2nd Tier).....	13
Downloader (1st Tier).....	14
NUMBER (2nd Tier).....	14
DL CODE (2nd Tier).....	14
Codes (1st Tier).....	15
INSTALL CODE (2nd Tier).....	15
DEALER CODE (2nd Tier)	15
DURESS CODE (2nd Tier).....	15
MANAGER (2nd Tier).....	15
MAINTENANCE CODE (2nd Tier).....	16
Timers (1st Tier)	16
ENTRY DLY (2nd Tier).....	16
EXIT DLY (2nd Tier).....	16
AUTO PHONE TEST (2nd Tier).....	16
QUIET TIME (2nd Tier)	16
QUIET HOUR (2nd Tier).....	17
REARM TIMER(2nd Tier)	17
Options (1st Tier).....	17
KTP ARM (2nd Tier)	17
POLICE PANIC (2nd Tier)	18
EMERGENCY PANIC (2nd Tier)	18
FIRE PANIC (2nd Tier)	18
RCVR TROUBLE (2nd Tier).....	18
PANEL TAMPER (2nd Tier).....	18
EXIT EXT (2nd Tier)	19
SWINGER SHUTDOWN (2nd Tier).....	19
QUICK ARM (2nd Tier)	19
QUICK EXIT (2nd Tier)	19
AUTO STAY ARM (2nd Tier)	20
SUPV TIME (2nd Tier).....	20
ALARM VERIFY (2nd Tier)	20
SMOKE VERIFY (2nd Tier).....	20
DEMO KIT (2nd Tier).....	21
Reports (1st Tier)	21
AC FAIL (2nd Tier).....	22
LOW CPU BATTERY (2nd Tier).....	22
PHONE TEST (2nd Tier).....	22
FIRE RESTORAL (2nd Tier).....	22
Siren (1st Tier).....	22
SIREN TIME OUT (2nd Tier).....	23
TROUBLE BEEPS (2nd Tier).....	23
ALARM VOLUME (2nd Tier).....	23
LOUD KTP BEEPS (2nd Tier)	23
Clear Memory (1st Tier)	23

EXIT DL (1st Tier)	23
<i>User Programing Menu Items</i>	24
Entering User Programming Mode.....	24
Codes (1st Tier).....	24
MANAGER (2nd Tier).....	24
MAINTANANCE CODE (2nd Tier)	24
PRIMARY (2nd Tier).....	25
USER 2, 3, 4 (2nd Tier).....	25
TIME (1st Tier).....	25
PHONE TEST (1st Tier).....	25
SENSOR TEST (1st Tier).....	26
VOLUME (1st Tier)	26
Version (1st tier).....	26
PANEL (2nd Tier)	26
PHONE MODULE (2nd Tier).....	26
Exiting User Programming Mode.....	26
<i>Downloader Programming</i>	27
ToolBox Downloader Programming.....	27
<i>Testing the System</i>	27
Basic System Commands.....	27
Testing Sensors/Zones	28
If a Wireless Sensor Does Not Test	29
Testing Phone Communication.....	29
Testing Central Station Communication.....	29
<i>Appendix A: Troubleshooting</i>	30
<i>Appendix B: Reference Tables</i>	35
Cross-Zoning	36
<i>Appendix C: Installation Menus</i>	40
<i>Appendix D: Software Release Notes</i>	41
Allegro Software Version 1.3.....	41
Dialog QS1000 Allegro Remote Station	41
Loud KTP Beeps.....	41
Smoke Verify	41
Dial Delay	41
SAW Sensors	41
Crystal Sensors	41
Force Arm Reporting.....	41
Exit Delay	41
Fire Restoral.....	41

<i>Notes</i>	<i>42</i>
<i>Specifications</i>	<i>43</i>

Special Installation Requirements

This security system can be used as an intrusion alarm system, a fire alarm system and an emergency notification system. Some installations may require configurations dictated by city/state codes, insurance, or Underwriter's Laboratories (UL). This section describes the various component and configuration listings.

UL Listed Systems

This section describes the requirements for UL Listed systems.

Basic System

- Control Panel (60-874-95R).
- Standard Class II 8.0 VAC, 300 mA Power Transformer - manufacturer: Sino America, (A1014444-0) GE Security Part No. 22-117 or Class II 9.0 VAC, 700 mA Power Transformer - manufacturers: Sino America (A30907CW), MG Electronics (AM-9700A), Leader Electronics (22-109-ITI) GE Security Part No. 22-109-ITI or Class II 9.0 VAC, 700 mA Power Transformer with cord - manufacturer: MG Electronics (22-131A) GE Security Part No. 22-131 or in Canada: Class II 9 VAC, 700 mA manufacturer: MG Electronics (22-109-CN) GE Security Part No. 22-109-CN
- Dialog™ Telephone Interface Module (DTIM) (60-879-95R).
- Backup Battery 4.8 VDC rechargeable NiCd battery pack (34-057).
- A 2 k Ohm EOL Resistor (49-467) is required for UL Listed systems.

Household Burglary Alarm System Unit (UL 1023)

Basic system, plus:

- Hardwire Magnetic Contact (13-068 or 13-071) or Wireless Learn Mode Door/Window Sensor (60-362), Wireless Learn Mode PIR Motion Sensor (60-703-95 or 60-639).
- RECEIVER TROUBLE set to on.
- EXIT DELAY set to 60 seconds or less. If Silent Exit feature is used EXIT DELAY set to 30 seconds.
- QUICK EXIT set to off.
- SIREN TIMEOUT set to 4 minutes or more.
- ENTRY DELAY set to 45 seconds or less.
- QUIET TIME set to off.

Household Fire Warning System (UL 985)

Basic system, plus:

- Wireless Smoke Sensor (60-506-319.5 or 60-848-95) learned into sensor group 26.
- RECEIVER TROUBLE set to on.
- QUIET TIME set to off.
- EXIT EXTENSION set to off.
- SIREN TIMEOUT set to 4 minutes or more.

Digital Alarm Communicator System (UL 1635)

Basic system, plus:

- AC FAILURE set to on.
- LOW CPU BATTERY set to on.
- AUTO PHONE TEST set to on.
- Combined ENTRY DELAY and abort window should not exceed 1 minute.

SIA System Requirements

SIA system requirements are the same as those described for a UL Listed Basic System, plus:

- If multiple annunciation is required, use Dialog QS1000 Allegro Remote Station (Part No. 60-982-95R)

SIA Setting Requirements

The following table describes programming requirements to meet ANSI-SIA CP-01

Table 1: SIA Requirements

Function	Programming Page Reference	Testing Page Reference	Default Setting	Required Setting
Entry Delay	16	28	30 Sec	30-240 Sec
Exit Delay	16	28	60 Sec	45-254 Sec
Dial Delay	11	29	30 Sec	15-45 Sec
Auto-Stay Arm	20	28	On	On
Pre-Dial String	11	29	None	Set if reporting to central station and customer has call waiting service.
Exit Extension	19	28	On	On
Swinger Shutdown	19	28	One trip	1-2 trips
Smoke Verify	20	28	Off	On
Duress Code	15	28	Disabled	Disabled
Alarm Verify/Cross Zoning	20	28	Disabled	Enabled for PIRs

The following table describes non-programmable (hard coded) system operation as required to meet ANSI-SIA CP-01 and is provided only for reference.

Table 2: Non-Programmable System Operation

Function	Operation
Silent Exit	All Annunciators Enabled
Remote Arming Exit Time & Progress Annunciation	All Annunciators Enabled
Abort Annunciation	Enabled
Cancel Report Annunciation	Enabled
Recent Closings	Enabled (2 Minute Window)
Exit Error	Enabled

Central Station Reporting

The panel has been tested with the following central station receivers using SIA and Contact ID reporting formats:

- CS-5000 Central Station Receiver.
- Sur-Gard Central Station Receiver with models SG-DRL2A and SG-CPM2.
- Osborne-Hoffman OH 2000 Central Station Receiver.

UL-Canada Listed Systems

This section describes the requirements for ULC (UL Canada) Listed systems.

- SIREN TIMEOUT set to 5 minutes.
- CSA Certified Accessories
- Residential Burglary Alarm System Unit (ULC-S309)
- Same as “UL Basic System and Household Burglary Alarm System Unit (UL 1023).” Except, transformer (22-117-CN or 22-109-CN) must be used.

California State Fire Marshall Listed Systems

Same as Household Fire Warning System (UL 985).

Planning the Installation

Note

Before beginning installation, installers must verify compatibility with the listed central station receivers indicated per installation.

Note

The DTIM does not have a backup battery.

Note

Both SAW and Crystal sensors function with Allegro.

See the Allegro Product Catalog for a complete list of compatible sensors.

This section describes the Allegro™ system's capabilities. It will help you get familiar with the system. Appendix B provides planning sheets with tables that let you record the hardware and programming configuration of the system to help prepare for system installation.

Standard System

Panel

The panel keypad provides complete system programming and operation control. Displays system messages and indicates system status.

The following describes the system's basic (out-of-box) hardware capabilities.

- Power: AC Class II, 8 or 9 VAC transformer.
- Backup Battery 4.8 VDC rechargeable NiCd battery pack (provides up to 24-hours of operation without AC power).
- One Supervised Hardwire Zone: Input for various hardwired detectors.
- Built-In Radio Receiver: Allows use of up to 20 GE Security 319.5 MHz. Crystal and/or SAW Learn Mode wireless sensors and touchpads.
- Built-In Siren: Capable of 85 dB @ 3m.
- Built-In Panel Keypad.
- Liquid Crystal Display (LCD).

DTIM

The Dialog Telephone Interface Module (DTIM) allows the panel to communicate with the central monitoring station.

Additional System Components

The system can monitor up to 20 sensors using any combination of the following sensors:

- Door/Window Sensor (60-670-95R)
- 2-Button Keychain Touchpad (60-607-319.5)
- Remote Handheld Touchpad (60-671-95R)
- Indoor Motion Sensor (60-639-95R)
- Carbon Monoxide Alarm (60-652-95) (Not investigated by UL)
- Smoke Sensor (60-848-95)
- ShatterPro Glass Break (60-873-95)
- Freeze Sensor (60-742-95R) or (60-504-10-319.5)
- Water Sensor (60-744-95R)
- Dialog QS1000 Allegro Remote Station (60-982-95R)

Installing the System

Before starting the installation, plan your system layout and programming using the worksheets provided in Appendix B.

Installing the system consists of the following:

- Determining the panel location.
- Mounting the panel.
- Identifying main panel components.
- Connecting detection devices to panel zone input.
- Installing an RJ-31X phone jack for the DTIM.
- Connecting the AC power transformer.
- Powering up the panel.

Important !

The panel must be mounted at least 10 feet from any other panel or DTIM.

Determine the Panel Location

Before permanently mounting the panel, determine panel location using the following guidelines:

- Avoid running wires parallel with electrical wiring or fixtures such as fluorescent lighting, to prevent wire runs from picking up electrical noise.
- Mount the panel at a comfortable working height (about 45 to 55 inches from the floor to the bottom of the panel).
- Leave space above the panel for optional antenna plastic (min. 4 inches).

Mounting the Panel

Use the following procedure to mount the panel to the wall or wall studs.



Static

You must be free of static electricity before handling circuit boards. Wear a grounding strap or touch a bare metal surface to discharge static electricity.

➤ **To mount the panel:**

1. Remove the panel from the back mounting plate by lifting the tab located on the top and pulling back.
2. Remove the wiring knockout.
3. Feed all device wires through the knockout and place the back mounting plate in position against the wall.
4. Level the back mounting plate and mark the top and bottom mounting holes.
5. Install anchors where studs are not present.
6. Partially insert a screw into the top mounting hole location then hang the back mounting plate on the screw.
7. Recheck for level, insert the lower screw, and tighten both mounting screws.
8. Install the antenna. There are three antenna options to choose from:




Figure 1. Tab location

- **Standard Range**- Leave the antenna as is.
- **Extended Range** - Attach the optional antenna housing (included in the accessory pack) to the panel.
 - a. Push the antenna housing down into the top right hole of the panel until it snaps into place (see Figure 2).
 - b. Remove the antenna loop from the last clip on the panel cabinet and insert it into the antenna housing.
- **Longest Range** - Hang the antenna in the wall.
 - a. When you mark the back mounting plate's two mounting holes, also mark where the antenna hole is (see Figure 2 for antenna wire hole location).
 - b. Where the antenna hole was marked, drill a hole into the wall.
 - c. Remove the antenna loop (see Figure 2) from the panel cabinet clips and feed through the antenna hole and down into the wall.

Note

The wiring knockout is approximately the same width as a wall stud. If mounting the panel to a wall stud be sure you have enough room to feed the wires through the knockout.




Figure 2. Antenna configurations

9. Place panel cabinet into back mounting plate and snap into place.

Connecting Detection Devices to Panel Zone Inputs

The zone input is supervised using a 2 k Ohm, end-of-line (EOL) resistor (included with panel) at the last device on the circuit. It accepts either normally open (N/O) or normally closed (N/C) detection devices.

The maximum loop resistance for each zone input is 300 ohms, plus the 2 k Ohm EOL resistor.

Connecting Intrusion Detection Devices

Figure 3 shows the typical wiring for N/C and N/O door/window intrusion detection.




Figure 3. Wiring N/O or N/C Intrusion Detection devices

Connecting the AC Power Transformer



Caution

Do not plug in the power transformer at this time. The panel must be powered up using the sequence of steps described in the “Powering up the Panel” section.




Figure 4. Connecting a Power Transformer

The panel must be powered by a UL approved transformer. Connect the power transformer to the panel as shown in Figure 4.

Note

In Canada, use the AC power transformer without a securing tab, (Part No. 22-117-CN or 22-109-CN).

Connecting the Backup Battery Pack

The panel will receive its primary power from an AC class II transformer. In the event of an AC power failure, the panel will be powered by a battery pack containing four rechargeable NiCd batteries.




Figure 5. Connecting the Battery Pack

➤ To connect the backup battery pack:

1. Remove the panel housing from the back mounting plate by lifting the tab located on the top of the panel and pulling back.

Note

Be sure to run the battery pack wires below the battery and through the wire channel.

2. Slide the battery pack into the space provided on the back of the panel (Figure 5).
3. Plug the battery pack lead into the slot provided next to the wire terminals (Figure 5).
4. Replace the panel housing on the back mounting plate and snap into place.

Note

Verify the front door is in place before replacing the panel on the mounting plate. It is not possible to attach the door after the panel is secured to the mounting plate.

Powering Up the Panel

After connecting and wiring all devices to the panel, you are ready to apply AC power to the panel.

➤ **To power up the panel:**

- Plug the transformer into an outlet that is not controlled by a switch or ground fault circuit interrupt (GFCI). Be sure to screw the top of the transformer onto the outlet so that it doesn't fall out of the outlet.
- If the DTIM is learned into the system (see "Learning the DTIM into the Panel" on page 7) the panel displays TEL MODULE INITIALIZING while the panel and the DTIM sync up. This will take approximately 5 minutes.
- To eliminate the 5 minute wait, remove and replace the DTIM cover after powering up the Allegro system.



Be careful when securing the transformer to an outlet with a metal cover. Hold the cover tightly in place. You could receive a serious shock if the metal outlet cover drops onto the prongs of the plug while you are securing the transformer and cover to the outlet box. If the panel does not display anything, immediately unplug the transformer and disconnect the backup battery. Refer to the "Troubleshooting" section.

Note

See "Appendix A: Troubleshooting" on page 30 if the panel displays LOW BATTERY.






Programming the Panel

This section describes how to navigate through the programming menus, clear memory, and learn the DTIM into the panel. You can program the panel manually using the panel keypad on site. Alternately, ToolBox[®] downloader software version 5.7 or later allows you to program remotely via a modem and phone line. See "Downloader Programming" on page 27.

Panel Keypad Button Programming Functions

In program mode, panel keypad buttons let you navigate to all installer programming menus for configuring the system. Table 3 describes the panel keypad button functions in program mode.

Table 3: Button Functions

Button	Programming Function
	Selects menu item or data entry (move to tier 2 programming). Toggles between on and off whenever needed.
	Deselects menu item or data entry (if pressed before #). Returns to the tier 1 program menu.
 	Scroll through available options at the current menu tier. Press ▼ to advance forward through the menus. Press ▲ to backup through the menus.
 (twice)	Deletes options that can be deleted.
0 - 9	Enter numeric values wherever needed.
1 - 6	Press and hold to enter A-F in account numbers.
Silent	Press to enter a pause in phone numbers. Pause displays as a "P".
7	Press and hold to enter "*" characters in phone numbers.
9	Press and hold to enter "#" characters in phone numbers.

Clearing Memory

It is strongly recommended that you clear memory on all newly installed panels before programming.

Clear memory deletes all existing programming information and then resets the panel settings to their default settings. The dealer code is not erased when panel memory is cleared.

➤ To clear panel memory:

1. Press 8, and enter the dealer or installer code. The display shows ACCOUNT.
2. Press ▲ twice. The display shows EXIT - DL; CLEAR MEMORY.
3. Press #.
4. Enter the dealer or installer code to clear memory.

Learning the DTIM into the Panel

The Dialog Telephone Interface Module is a battery operated communication link between the security system control panel and the central monitoring station. The DTIM receives radio signals from the panel, then uses the phone line to report security system events to the central monitoring station. See the *Dialog Telephone Interface Module Installation Instructions* (466-1849) for complete installation instructions.

The DTIM uses a 3-2-1 tamper switch activation sequence for learning, which causes the LED to blink in a corresponding 3-2-1 sequence. You must wait for the LED to turn off after each flash sequence before releasing the tamper switch (see Figure 6).

➤ To learn the DTIM into the panel:

1. Remove the DTIM cover and set it aside.
2. Install the antennas. (See the *DTIM Installation Instructions*.)

Note

Antennas must be installed and the DTIM should be at least 10 feet from the panel for learning.

3. With the system disarmed, enter program mode by pressing 8 + code.
4. Press ▼ twice and # twice. The display shows ZONE 01 - TRIP.
5. Locate the DTIM tamper switch and LED (see Figure 6).
6. Press and release the DTIM's tamper switch as follows:
 - a. Press 3 times, holding the tamper switch down on the third press until the LED flashes 3 times, then release after the third flash.
 - b. Immediately press 2 times holding the tamper switch down on the second press until the LED flashes 2 times, then release after the second flash.
 - c. Immediately press and hold, then wait for the panel to beep once indicating it learned the DTIM. Release the tamper switch.
7. Proceed to programming the rest of the panel or exit from program mode.




Figure 6. DTIM Tamper Switch and LED Locations

Important !

Timing is the key to success in step 6. Do not wait more than 1 second between tamper switch activations. If you wait too long, the LED will not flash and you must start over. If you release the tamper switch before the LED is done flashing you must start over.

Installer Programming Menus

This section guides you through the installer programming menus. There are three tiers of programming menus. Tier 1 menus are accessible immediately after entering program mode. Refer to Table 3 on page 6 for information on navigating the programming menus and Appendix C for a diagram of all programming menus.

Entering Installer Programming Mode

Entering programming mode on site is done from the panel, using an installer code. The default installer code is 4321. The system can be put into program mode only when the system is disarmed.

➤ **To enter programming mode:**

With the system disarmed, press 8 + code.

Account Menu (1st Tier)

The account menu lets you set up the account number used for customer identification by the central monitoring station.

ACCOUNT (1st Tier)	(ACCOUNT—)
Default = 00000, Parameters = 4-10 digits; 0-9, A-F)	
The account number is used as panel (or customer) identification for the central monitoring station. The panel sends the account number every time it reports to the central station. Account numbers must be 4 to 10 characters long.	
Alpha characters A–F can be assigned to the account number by pressing and holding buttons 1–6 respectively, until the character appears.	
➤ To program an account number:	
◆ Press #, then enter the 4-10 digit code (0-9 and A-F) and press #.	

Note

The CID format only supports 4-digit account numbers with letters B through F, or numbers 0 through 9 (or a combination of those letters and numbers).

Phones Menu (1st Tier)

The PHONES menu lets you set up central station reporting for the Allegro system.

Phone 1 and Phone 2 (2nd Tier)

Each 2nd tier PHONE menu contains the following 3rd tier menus:

- NUMBER 1 and NUMBER 2
- FMT - CID
- HIGH LVL
- LOW LVL
- OPENINGS
- CLOSINGS
- BACKUP (Only under PHONE 2.)

Note

The phone numbers are not accessible if a Dealer Code is programmed and the Installer Code is used to enter installer programming mode. To access these numbers when a Dealer Code is programmed, you must enter installer programming mode using the Dealer Code.

Call-waiting services should be disabled to prevent interrupting panel communication to the central monitoring station. To program a dialing prefix that disables call-waiting, see Pre-Dial String on 11.

NUMBER 1 and NUMBER 2 (3rd Tier) (PHONES—PHONE 1 & PHONE 2—)

*(Default = none, Parameters = 24 digits; 0-9, *, #)*

This setting is used for programming the central station receiver phone number. Phone numbers can be 1 to 24 digits long, including pauses or * and # characters.

- ◆ To enter pauses, press the silent key. A pause is displayed as P.
- ◆ To enter *, press and hold the 7 key until * appears. A star (*) is displayed as *.
- ◆ To enter #, press and hold the 9 key until + appears. A pound (#) is displayed as +.
- ◆ To clear phone number, press Quick Exit.

➤ **To program Number 1 or 2:**

- ◆ Enter 1-24 digit number and press #.

➤ **To delete Number 1 or 2:**

- ◆ Press # twice. Once to delete the code and again to accept the command.

FMT - CID (3rd Tier) (PHONES—PHONE 1 & PHONE 2—)

(Default = CID)

This setting determines whether the system uses the SIA (Off) or CID (On) reporting format for central station communication.

➤ **To select reporting format under phone 1 or 2:**

- ◆ Press # to select on or off.

HIGH LVL (3rd Tier) (PHONES—PHONE 1 & PHONE 2—)

(Default = Phone 1: on, Phone 2: off, UL Installations = On)

When High Level Reporting is on, the following conditions report to the central station:

- Fire, Police, Emergency, and Duress alarms
- Phone Test
- Receiver Trouble
- Tamper Alarm Conditions, including Zone Tamper and System Tamper
- Cancel Report
- Exit Error
- RF Interference
- Recent Closing

➤ **To turn High Level reports on or off under Phone 1/2:**

- ◆ Press # to turn it on or off.

LOW LVL (3rd Tier)	(PHONES—PHONE 1 & PHONE 2—)
<i>(Default = Phone 1: on, Phone 2: off, UL installations = On)</i>	
When this setting is on, the following non-alarm conditions report to the central station:	
<ul style="list-style-type: none"> • AC Failure • Forced Arming • Entering or Exiting Sensor Test Mode • Hardwire Zone Trouble • RF Supervisory • RF Low Battery • Low Panel Battery • Phone Test 	
➤ To turn Low Level reports on or off under Phone 1/2:	
◆ Press # to turn it on or off.	
OPENINGS (3rd Tier)	(PHONES—PHONE 1 & PHONE 2—)
<i>(Default = Off)</i>	
This setting determines whether an opening report is sent to the central station. When turned on, the panel sends an opening report when the system is disarmed.	
➤ To turn Openings reports on or off under Phone 1 or 2:	
◆ Press # to turn it on or off.	
CLOSINGS (3rd Tier)	(PHONES—PHONE 1 & PHONE 2—)
<i>(Default = Off)</i>	
This setting determines whether a closing report is sent to the central station. When turned on, the panel sends a closing report when the system is armed.	
➤ To turn Closings reports on or off under Phone 1 or 2:	
◆ Press # to turn it on or off.	
BACKUP (3rd Tier)	(PHONES—PHONE 2—)
<i>(Default = On)</i>	
This setting determines whether the DTIM uses phone number 2 for reporting if three initial attempts on phone number 1 are unsuccessful. PHONE 1 is backed up by PHONE 2. The DTIM makes up to 16 attempts (8 per phone number), alternating between the two programmed phone numbers.	
For example, if Backup is on and three failed reporting attempts occur using PHONE 1, (panel displays PHONE 1 FAIL), the DTIM switches to PHONE 2 for three more reporting attempts. If these attempts fail, (panel displays PHONE 2 FAIL), the DTIM switches back to PHONE 1 for five more reporting attempts and, if necessary, switches back to PHONE 2 for five final attempts. If these final attempts fail, the panel will display PHONE FAILURE.	
➤ To turn Backup on or off:	
◆ Press # to turn it on or off.	

Note
Fire alarm reports to the central station cannot be aborted.

DIAL DLY (2nd Tier)	(PHONES—)
(Default = 30 seconds, Parameters = 15-45 seconds)	
Alarm reports from sensors in groups 00–01, 04, 06, 08-10, 13-20, 29 and 38 can be aborted. To abort the dialing attempt, the user must disarm the system within the Dial Delay time setting. Cancel and restoral reports from these sensor groups are aborted at the same time. The following reports can also be aborted.	
<ul style="list-style-type: none"> • System Tamper Alarm/Cancel • Touchpad Police and Emergency Panic/Cancel • Forced Arming • Recent Closing 	
<p>➤ To set the Dial Delay:</p> <ul style="list-style-type: none"> ◆ Enter the desired amount of time (15-45 seconds) and then press #. 	
PRE-DIAL STRING (2nd Tier)	(PHONES—)
(Default = none, Parameters = 8 digits; 0-9, *, #, pause)	
This feature lets you set up a dialing prefix to disable the call waiting feature before the panel makes its first dialing attempt to any programmed central monitoring station or downloader phone number. The prefix can be up to eight digits. Contact your local phone company for call waiting disable numbers and characters. See Number 1 and 2 (3rd Tier) on Page 9 for information on how to program *, #, and pause characters.	
<p>Important ! Programming a call waiting disable string on a phone line that does not have call waiting will prevent successful communication with the central station.</p>	
<p>➤ To set the Pre-Dial String:</p> <ul style="list-style-type: none"> ◆ Enter the desired numbers and then press #. 	
<p>➤ To delete Pre-Dial String:</p> <ul style="list-style-type: none"> ◆ Press # twice. Once to delete the code and again to accept the command. 	
DTMF DIAL (2nd Tier)	(PHONES—)
(Default = On)	
This setting determines whether the panel uses DTMF tones (On) or pulse (Off) for dialing programmed phone numbers.	
<p>➤ To turn DTMF dialing on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn it on or off. 	

Note
The pre-dial string is not accessible if a Dealer Code is programmed and the Installer Code is used to enter installer programming mode. To access the pre-dial string option when a Dealer Code is programmed, you must enter installer programming mode using the Dealer Code.

Devices (1st Tier)

Devices include a HW sensor, RF sensors, RF touchpads, and other RF devices such as the DTIM. The following 2nd tier menus allow you to set up devices:

- ADD
- DELETE
- REVIEW
- TEXT

Note

See Table B1, in Appendix B for more information on sensor groups.

The Carbon Monoxide Detector must be changed to sensor group 34 to ensure proper supervision.

The SAW Freeze Sensor must be changed to sensor group 29 to ensure proper supervision.

The Water Sensor must be changed to sensor group 38 to ensure proper supervision.

The Dialog QS1000 Allegro Remote Station's zone input is assigned to sensor group 10.

Table 4: Sensor Group Assigned to Device

Device	Sensor Group
Keyfob or RF Touchpad	1
Portable Panic	1
HW Input	10
DWS	10
Carbon Monoxide Detector (See Note)	10 (See Note)
Freeze Sensor	10 (See Note)
Water Sensor	10 (See Note)
PIR	17
Sound	17
Glassguard	17
Smoke	26
Rate of Rise	26
DTIM	39
Dialog QS1000 Allegro Remote Station	10 (See Note)

Note

When installing Crystal sensors and encrypted keychain touchpads, use the installation instructions included with the sensor.

Table 5: Device Programming

Device	To Program
Door/Window Sensor (SAW)	Press button on top of sensor (cover removed).
Motion Sensor	Press and release the button on back of sensor (mounting plate removed).
Keychain Touchpad (non encrypted)	Press lock & unlock buttons until LED blinks.
Keychain Touchpad (encrypted)	See Note.
Crystal Sensors	See Note.
DTIM	3-2-1 sequence (7).
Hardwire Sensor	For normally closed - separate sensor from magnet. For normally opened - close sensor then reopen.
Carbon Monoxide Alarm	Plug in the module and within 30 seconds, press and hold the TEST/RESET button until you hear 6 beeps.
Freeze and Water Sensor	Trip the sensor as described in Table 8, then press and hold the button on top of sensor (cover removed) until the system confirms programming.
Dialog QS1000 Allegro Remote Station	Press and hold the Police Panic buttons for 2 seconds.

Note

To override the preassigned sensor number, use the arrow keys to skip to the desired sensor number.

ADD (2nd Tier)	(DEVICES—)
(Default = None)	
When adding devices, the panel will automatically assign the device to a sensor group based on the type of device. Table 4 outlines the sensor group assigned to each device.	
➤ To add a device:	
1. Press #. The display shows ZONE {01- 20} - TRIP.	
2. Trip the sensor (see Table 5). The panel beeps twice to indicate the sensor was successfully learned into the panel.	
3. Repeat step 2 until all desired zones are added.	

Note
Deleting zones/sensors does not delete text associated with the deleted zone/sensor number.

Important !
Review devices allows the installer to change the group assigned to devices. The panel accepts the group numbers defined in Table B1, in Appendix B.

Note
The text for the Zone in which the DTIM is learned into is automatically set to Phone Module when it is enrolled.

Note
Some combinations of sensor text selections are too long for the display.

DELETE (2nd Tier)	(DEVICES—)
(Default = None)	
The following procedure describes how to remove hardwire and wireless sensors from panel memory.	
➤ To delete a device:	
<ol style="list-style-type: none"> 1. To select a different zone press ▼ to scroll through the learned zones. Press # to delete the displayed zone. The display shows the next sensor. 2. Repeat step 1 until all desired zones are deleted. 	
REVIEW (2nd Tier)	(DEVICES—)
(Default = None)	
This allows you to view the zone number and the group for each learned zone or sensor. For example, the display shows:	
ZONE 01 GRP 10	
where:	
ZONE 01 = zone/sensor number, GRP 10 = sensor group 10.	
➤ To review a device:	
<ol style="list-style-type: none"> 1. To select a different zone press ▼ to scroll through the learned zones. The display shows the current setting. 2. Enter the desired group number to modify then press #. The display shows the new setting. 	
TEXT (2nd Tier)	(DEVICES—)
(Default = None)	
The panel allows sensor text to be associated with each device. The sensor text consists of a prefix field, base field, and suffix field. Table 6 on page 14 shows the words available for each field. The default text for zones 2-3 are:	
<ul style="list-style-type: none"> • Zone 2 - Front Door • Zone 3 - Back Door 	
➤ To add text:	
<ol style="list-style-type: none"> 1. To select the zone you want to add text to press ▼, till you get to the correct zone then press #. Base is the first to be displayed. 2. Press # then ▼ to scroll through the base words, press # to select the word you want. 3. Press ▼ to change to the prefix words. Press # then ▼ to scroll through the prefix words. Press # to select the word you want. 4. Press ▼ to change to the suffix words. Press # then ▼ to scroll through the suffix words. Press # to select the word you want. 5. Press * to review what has been selected, then press ▼ to go to the next zone to change. 6. Repeat steps 2 through 5 to change all zones. 	

Table 6: Sensor Text

Prefix Field	Base Field	Suffix Field	Prefix Field	Base Field	Suffix Field
None	None	None		Kitchen	4
North	Keychain	Door		Office	5
NE	Touchpad	Window		Den	6
East	Front	Remote		Special Chime	7
SE	Back	Smoke		Basement	8
South	Garage	Emergency		Upstairs	9
SW	Bedroom	Motion		Downstairs	
West	Guest Room	Fire		Hallway	
NW	Childs Room	Freeze		Medicine Cabinet	
	Utility Room	CO		Closet	
	Living Room	0		Attic	
	Dining Room	1		System Panic	
	Bathroom	2		Phone Module	
	Laundry Room	3			

Downloader (1st Tier)

The DOWNLOADER menu lets you set up the Allegro panel for use with ToolBox downloader software. The DOWNLOADER menu contains the following 2nd tier menus:

- NUMBER
- DL CODE

NUMBER (2nd Tier) (DOWNLOADER—)

*(Default = none, Parameters = 24 digits; 0-9, *, #, pause)*

Use this setting to enter the phone number of an off-site computer that can be used to program the panel through the phone line. Phone numbers can be 1 to 24 digits long, including pauses or * and # characters (see “Number 1 and 2 (3rd Tier)” on 9).

Note

The phone numbers are not accessible if a Dealer Code is programmed and the Installer Code is used to enter installer programming mode. To access these numbers when a Dealer Code is programmed, you must enter installer programming mode using the Dealer Code. For this feature to work, the DTIM must be connected to a phone line with a Downloader phone number, and with a Downloader code. Call-waiting services should be disabled to prevent interrupting panel communication to the downloader. To program a dialing prefix that disables call-waiting, see the Pre-dial String setting 11.

➤ **To program a Downloader Number:**

- ◆ Enter 1-24 digit number and then press #.

➤ **To delete a Downloader Number**

- ◆ Press # twice. Once to delete the number and again to accept the command.

DL CODE (2nd Tier) (DOWNLOADER—)

(Default = 12345, Parameters = 5 digits; 0-9)

The 5-digit downloader code is used in conjunction with downloader programming. The downloader operator must have the panel account number, dealer code, and downloader code in order to perform any programming.

➤ **To program a Downloader Code:**

- ◆ Enter 5-digit code and then press #.

Note

The Downloader Code cannot be deleted from panel memory. To change the Downloader Code to its default setting, enter 12345 when programming the Downloader code.

Codes (1st Tier)

The CODES menu lets you define codes for the Allegro system. The CODES menu contains the following 2nd tier menus, or codes:

- INSTALL CODE
- DEALER CODE
- DURESS CODE
- MANAGER
- MAINTENANCE CODE

INSTALL CODE (2nd Tier)	(CODES—)
<i>(Default = 4321, Parameters = 4 digits; 0-9)</i>	
The 4-digit installer code is used for entering program mode and changing system settings. If a dealer code is programmed, all settings except phone numbers, pre-dial string, and downloader number and dealer code can be changed.	
➤ To change an Installer Code:	
◆ Enter 4-digit code and then press #.	
DEALER CODE (2nd Tier)	(CODES—)
<i>(Default = none, Parameters = 4 digits; 0-9)</i>	
The 4-digit dealer code is used to prevent unauthorized persons from changing the programmed central station phone numbers. When this feature is enabled, central station phone numbers, pre-dial string, and downloader phone number cannot be changed (unless you enter the program mode by using the dealer code). All <i>other</i> system settings are still accessible by entering program mode with the installer code.	
➤ To program a Dealer Code:	
◆ Enter 4-digit code and then press #.	
➤ To delete a Dealer Code:	
◆ Press # twice. Once to delete the code and again to accept the command.	
DURESS CODE (2nd Tier)	(CODES—)
<i>(Defaults = none, Parameters = 4 digits; 0-9)</i>	
The duress code is a unique 4-digit access code that allows users to operate the system and, at the same time, instructs the panel to send a silent alarm report to the central station.	
➤ To program a Duress Code:	
◆ Enter 4-digit code and then press #.	
➤ To delete a Duress Code:	
◆ Press # twice. Once to delete the code and again to accept the command.	
MANAGER (2nd Tier)	(CODES—)
<i>(Default = none, Parameters = 4 digits; 0 to 9)</i>	
The manager code functions the same as the primary code within the user programming menu, and can arm or disarm the system.	
➤ To program Manager Code:	
◆ Enter 4-digit code and then press #.	
➤ To delete the Manager Code:	
◆ Press # twice. Once to delete the code and again to accept the command.	

Note

When memory is cleared the dealer code will not be deleted from panel memory.

If a dealer code has already been programmed into the system, use that code to change the dealer code.

MAINTENANCE CODE (2nd Tier)	(CODES—)
<i>(Default = none, Parameters = 4 digits, 0 to 9)</i>	
<p>The maintenance code is to be used in conjunction with the apartment manager keychain touchpad. When a maintenance person needs access to a site protected by an Allegro, he can press disarm on the apartment manager keychain touchpad, enter the premises, then disarm using the maintenance code at the panel.</p>	
<p>➤ To program the Maintenance Code:</p> <ul style="list-style-type: none"> ◆ Press #, enter the desired code and then press #. 	
<p>➤ To delete the Maintenance Code:</p> <ul style="list-style-type: none"> ◆ Press # twice. Once to delete the code and again to accept the command. 	

Timers (1st Tier)

The TIMERS menu lets you set up the following 2nd tier timers for the Allegro system:

- ENTRY DLY
- EXIT DLY
- AUTO PHONE TEST
- QUIET TIME
- QUIET HOUR
- REARM TIMER

ENTRY DLY (2nd Tier)	(TIMERS—)
<i>(Default = 30 seconds, Parameters = 30-240 seconds, UL installations = 45 seconds)</i>	
<p>Entry Delay determines how much time the user has to disarm the system after entering the armed premises through a “designated delay door,” (grp 10) without causing an alarm.</p>	
<p>➤ To set the Entry Delay:</p> <ul style="list-style-type: none"> ◆ Press #, enter desired time and then press #. 	
EXIT DLY (2nd Tier)	(TIMERS—)
<i>(Default = 60 seconds, Parameters = 30-254 seconds, UL installations = 60 seconds)</i>	
<p>Exit Delay determines how much time the user has after arming the system to leave the premises through a “designated delay door,” (group 10 or 19) without causing an alarm.</p>	
<p>➤ To set the Exit Delay:</p> <ul style="list-style-type: none"> ◆ Press #, enter desired time and then press #. 	
AUTO PHONE TEST (2nd Tier)	(TIMERS—)
<i>(Default = 0 days, Parameters = 0-255 days)</i>	
<p>Auto Phone Test determines how often the panel conducts the automatic phone test. The system can be set to perform an automatic phone test anywhere from every day to every 255 days. Set this option to 0 to turn off.</p>	
<p>➤ To set the Auto Phone Test:</p> <ul style="list-style-type: none"> ◆ Press #, enter desired number of days and then press #. 	
QUIET TIME (2nd Tier)	(TIMERS—)
<i>(Default = On, UL installations = Off)</i>	
<p>Quiet Time determines whether quiet hour is enabled or disabled. If enabled, proceed to Quiet Hour to set the quiet time desired.</p>	
<p>➤ To set the Quiet Time:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	

Important !
Fire related trouble beeps are not affected by Quiet Time.

QUIET HOUR (2nd Tier)	(TIMERS—)
<i>(Default = 22, Parameters = 0-23)</i>	
<p>Quiet Hour determines the start time of a 10 hour window during which trouble beeps are suppressed. For example, if quiet hour is set to 22 (10 p.m.) then non-fire related trouble beeps will not start between 10 p.m. and 8 a.m.</p> <p>➤ To set the Quiet Hour:</p> <ul style="list-style-type: none"> ◆ Enter desired time (00-23) and then press #. 	
REARM TIMER(2nd Tier)	(TIMERS—)
<i>(Default = 0, Parameters = 0-12 hours)</i>	
<p>Rearm timer determines how long the system will remain disarmed before it rearms to the previous level if disarmed with the Allegro Keychain Access Manager. See the <i>Allegro Keychain Access Manager Instructions</i> for more information on its use.</p> <p>➤ To set the Rearm Timer:</p> <ul style="list-style-type: none"> ◆ Press #, enter desired number of hours and then press #. 	

Options (1st Tier)

The OPTIONS menu allows you to program the following 2nd tier security options:

- KTP ARM
- POLICE PANIC
- EMERGENCY PANIC
- FIRE PANIC
- RCVR TROUBLE
- PANEL TAMPER
- EXIT EXT
- SWINGER SHUTDOWN
- QUICK ARM
- QUICK EXIT
- AUTO STAY ARM
- SUPV TIME
- ALARM VERIFY
- SMOKE VERIFY
- DEMO KIT

KTP ARM (2nd Tier)	(OPTIONS—)
<i>(Default = off)</i>	
<p>When Keychain Touchpad Arm is on, pressing the lock button on keychain touchpads arms the system directly to Level 3 with NO DELAY.</p> <p>When this setting is off, each key-press increments the arming level without NO DELAY.</p> <p>➤ To turn keychain touchpad arm on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	

<i>POLICE PANIC (2nd Tier)</i>	<i>(OPTIONS—)</i>
<i>(Default = on)</i>	
<p>This setting determines whether panel keypad police panic buttons are enabled (on) or disabled (off). If enabled, an immediate Police alarm will occur after the police panic buttons are pressed for two seconds and the panel displays the alarm as a police panic. If the DTIM is installed with the system;</p> <ul style="list-style-type: none"> • An alarm report will be issued. • If the dialer delay option is on, the report will be delayed or can be aborted. <p>➤ To turn the police panic on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	
<i>EMERGENCY PANIC (2nd Tier)</i>	<i>(OPTIONS—)</i>
<i>(Default = off)</i>	
<p>This setting determines whether panel keypad emergency panic buttons are enabled (on) or disabled (off). If enabled, an immediate alarm will occur after the emergency panic buttons are pressed for two seconds and the panel displays the alarm as an emergency panic. If the DTIM is installed with the system;</p> <ul style="list-style-type: none"> • An alarm report will be issued. • If the dialer delay option is on, the report will be delayed or can be aborted. <p>➤ To turn the emergency panic on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	
<i>FIRE PANIC (2nd Tier)</i>	<i>(OPTIONS—)</i>
<i>(Default = on)</i>	
<p>This setting determines whether panel keypad fire panic buttons are enabled (on) or disabled (off). If enabled, an immediate Fire alarm will occur after the fire panic buttons are pressed for two seconds and the panel displays the alarm as a fire panic. If the DTIM is installed with the system, an immediate alarm report will be issued.</p> <p>➤ To turn the fire panic on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	
<i>RCVR TROUBLE (2nd Tier)</i>	<i>(OPTIONS—)</i>
<i>(Default = off, UL installations = on)</i>	
<p>When Receiver Trouble is on, the panel reports a receiver failure under the following conditions:</p> <ul style="list-style-type: none"> • A wireless sensor signal has not been received for two hours or • The receiver is being jammed with a constant signal. <p>➤ To turn receiver trouble reports on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	
<i>PANEL TAMPER (2nd Tier)</i>	<i>(OPTIONS—)</i>
<i>(Default = on)</i>	
<p>Panel Tamper determines how the panel handles possible tamper situations. When this feature is on, the panel reports a panel tamper if the panel back cover or DTIM cover is opened while the panel is armed. A police alarm will sound and PANEL TAMPER or PHONE MODULE TAMPER will be displayed. If this feature is off or the system is disarmed the panel will display a status message only.</p> <p>➤ To turn the panel tamper on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	

Note
The fire panic alarm report cannot be aborted or cancelled.

EXIT EXT (2nd Tier)	(OPTIONS—)
<i>(Default = on, UL installations = off)</i>	
<p>When Exit Extension is on, the panel restarts the exit delay timer if the user re-enters the premises through a standard delay door before the standard exit delay time expires.</p> <p>This helps prevent exit faults and false alarms by allowing users to re-enter the premises for a forgotten item.</p> <p>When this feature is off, the exit delay timer does not restart if the user re-enters the premises, forcing the user to disarm the system to avoid setting off an accidental alarm.</p> <p>➤ To turn exit extension on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	
SWINGER SHUTDOWN (2nd Tier)	(OPTIONS—)
<i>(Default = 1, Parameters = 1-2)</i>	
<p>This setting determines the maximum number of times a sensor or zone can go into alarm (during a single arming period) before the panel automatically bypasses that sensor or zone. This feature applies to all sensors groups except the fire (26), DTIM (29), and special chime (25) groups.</p> <p>When set to 1, the panel automatically bypasses a sensor or zone after it causes an alarm. When set to 2, the panel waits until a sensor or zone has caused a second alarm (during the same arming period) before bypassing it.</p> <p>Changing the arming level also clears all bypassed sensors and zones and resets the Swinger Limit count on all sensors and zones.</p> <p>➤ To set the swinger shutdown:</p> <ul style="list-style-type: none"> ◆ Press #, enter desired number and then press #. 	
QUICK ARM (2nd Tier)	(OPTIONS—)
<i>(Default = off)</i>	
<p>Quick Arm allows system arming without using an access code. When Quick Arm is on, the system arming level can be increased without entering an access code.</p> <p>A valid access code is still required to disarm the system.</p> <p>➤ To turn quick arm on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	
QUICK EXIT (2nd Tier)	(OPTIONS—)
<i>(Default = on, UL installations = off)</i>	
<p>This setting determines whether or not users can open and close a standard entry/exit door without causing an alarm (while the system is armed).</p> <p>When Quick Exit is on and the system is armed, pressing Quick Exit starts a 2 minute timer. During the two minutes exit or entry is allowed through a standard entry/exit door (sensor group 10). You may open and close the entry/exit door as many times as necessary within the two minutes.</p> <p>When this feature is turned off, the system must be disarmed if a protected door is opened.</p> <p>➤ To turn Quick Exit on or off:</p> <ul style="list-style-type: none"> ◆ Press # to turn on or off. 	

Note

Arming the system to "Level 3 with No Delay" or arming to Level 3 from a keychain touchpad or hand held touchpad overrides the Auto Stay Arming feature.

AUTO STAY ARM (2nd Tier) (OPTIONS—)

(Default = on)

This setting determines whether or not the system automatically arms only doors and windows if the user arms the system without exiting the premises. This can help prevent accidental alarms by deactivating interior motion sensors during occupied arming periods.

When this feature is on and the system is armed, the display counts down the exit delay time. If the exit delay time expires with no group 10 sensor activation, the system automatically arms to Level 2, doors and windows.

- **To turn Auto Stay Arm on or off:**
 - ◆ Press # to turn on or off.

Note

The panel clock must be set with the correct time for accurate supervisory time reporting. See "Time (1st Tier)" on 25.

SUPV TIME (2nd Tier) (OPTIONS—)

(Default = from 1:00 AM to 3:59 AM, Parameters = 12:00 AM - 11:59 PM)

Supervisory Time determines what time of day the panel sends supervisory, low battery, and auto phone test reports to the central station.

- **To set the Supervisory Time:**
 - ◆ Press #, enter desire time, use scroll keys to select am or pm, and then press #.

Note

The first trip of a sensor will be a local alarm (doesn't call in), the second trip must be a different sensor within 4 minutes of the first trip.

ALARM VERIFY (2nd Tier) (OPTIONS—)

(Default = off, UL Listed installations = set to off)

This setting determines whether the panel reports to the central monitoring station after a single sensor or zone trip (off) or waits for a second trip before reporting (on).

This setting affects sensors/zones in groups 10 through 20. If Alarm Verify is set to on, group 18 responds the same as group 17.

- **To turn Alarm Verify on or off:**
 - ◆ Press # to turn on or off.

Note

When enabled, the first trip of a sensor will be a local alarm. The second trip must occur while the siren is sounding from the first trip.

Note

Performing a download to an Allegro panel with software version 1.3 with ToolBox version 5.7 will turn this feature off. Version 5.7.1 fixes this issue.

SMOKE VERIFY (2nd Tier) (OPTIONS—)

(Default = off)

This setting determines whether the panel reports to the central monitoring station after a single trip of a group 26 (Fire) sensor (off) or waits for a second group 26 sensor trip or a repeat message from the first sensor before reporting (on)

- **To turn Smoke Verify on or off:**
 - ◆ Press # to turn on or off.

(Default = off)

This setting determines whether the panel is used for a standard installation (Off) or as a demo kit (On). The demo kit (80-702) will include:

- Allegro panel
- SAW D/W
- 2 button key fob
- PIR plastic (motion sensor)
- DTIM plastic
- 9V alkaline battery with battery strap
- Soft-sided case
- Demo kit Instructions

The following contains the modifications to Allegro Software that embody the Demo Kit Software. All features work exactly as on the production version except those listed here.

➤ To put the panel into demo kit mode:

1. Press # to turn Demo Kit on.
2. Clear the panel memory (see “Clear Memory (1st Tier)” on page 23)

The power-up defaults are the same as the production version except the following:

Sensor Text

- ZONE 1 = KEYCHAIN REMOTE
- ZONE 2 = FRONT DOOR

Options

- Demo kit = On
- CPU low battery = Off
- Quick arming = On
- Panel panics = On
- Entry delays = 8 seconds
- Exit delays = 8 seconds
- Siren time-out = 1 minute
- Trouble beeps = Off
- Panel tamper = Off

All program items can be changed by the operator but will return to defaults upon a memory clear execution.

Behavioral Differences

A transformer is not required for the Demo Kit. AC power tests will never be performed and AC power failure will never be shown.

- The prompt for setting time after a power cycle will never be shown.

Reports (1st Tier)

The REPORTS menu allows you to set up the Allegro panel to perform the following central station reports:

- AC FAIL
- LOW CPU BATTERY
- PHONE TEST
- FIRE RESTORAL

AC FAIL (2nd Tier)	(REPORTS—)
<i>(Default = off, UL installations = on)</i>	
When AC Failure is on, the panel reports to the central station 15 minutes after AC power to the panel is lost.	
➤ To turn AC failure reports on or off:	
◆ Press # to turn on or off.	
LOW CPU BATTERY (2nd Tier)	(REPORTS—)
<i>(Default = on, UL installations = on)</i>	
When this setting is on, the panel reports a low panel battery to the central station.	
➤ To turn low CPU battery reports on or off:	
◆ Press # to turn on or off.	
PHONE TEST (2nd Tier)	(REPORTS—)
<i>(Default = on)</i>	
This setting determines if the user can, at any time when disarmed, test the communication between the panel and the central station. If a DTIM is installed with the system:	
<ul style="list-style-type: none"> • The panel sends a packet to the DTIM informing it to send a phone test report to the central station. The report will be sent out immediately. • The DTIM will send a successful or failed phone test message to the panel. • The panel will display PHONE TEST FAILURE, if the phone test is unsuccessful. • The panel will display TEST PASS, if the phone test is successful. • If a central station phone number is not programmed the panel will not display the option to do a phone test. • If a DTIM is not enrolled the panel will not display the option to do a phone test. • High or Low level reporting must be on. 	
➤ To turn the phone test setting on or off:	
◆ Press # to turn on or off.	
FIRE RESTORAL (2nd Tier)	(REPORTS—)
<i>(Default = off)</i>	
When this setting is on, the panel reports a restoral report to the central station when a group 26 (Fire) sensor in alarm is restored. No report is sent when this option is off.	
The report is not sent if the sensor restoral occurs after the alarm is cancelled.	
➤ To turn the phone test setting on or off:	
◆ Press # to turn on or off.	

Note
Panel will not call in a low CPU battery within the first 24 hours of being powered up.

Siren (1st Tier)

The SIREN menu allows you to set up the following siren options:

- SIREN TIME OUT
- TROUBLE BEEPS
- ALARM VOLUME
- LOUD KTP BEEPS

SIREN TIME OUT (2nd Tier)	(SIRENS—)
<i>(Default = 4 minutes, Parameters = 1-30, UL installations = 4 minutes)</i>	
Siren Time-out determines how long sirens sound if no one is present to disarm the system.	
➤ To set Siren Time Out:	
◆ Press #, enter the desired time and then press #.	
TROUBLE BEEPS (2nd Tier)	(SIRENS—)
<i>(Default = on, UL installations = on)</i>	
When this setting is on, the panel will beep to alert users of system trouble.	
➤ To turn Trouble Beeps on or off:	
◆ Press # to turn on or off.	

ALARM VOLUME (2nd Tier)	(SIRENS—)
<i>(Default = 6, Parameters = 0 to 6, UL installations = 6)</i>	
This setting allows you to adjust the panel's siren volume. The volume can be set from 0 to 6, with 0 being the lowest volume.	
➤ To set the Alarm Volume:	
◆ Press #, enter the desired volume level and then press #.	
LOUD KTP BEEPS (2nd Tier)	(REPORTS—)
<i>(Default = off)</i>	
This setting allows you to set the volume of the beeps that sound when the system is armed or disarmed with a keychain touchpad. The volume can be set low (off) or high/loud (on).	
➤ To turn Loud KTP Beeps on or off:	
◆ Press # to turn on or off.	

Note
Performing a download to an Allegro panel with software version 1.3 with ToolBox version 5.7 will turn this feature off. Toolbox version 5.7.1 fixes this issue.

Clear Memory (1st Tier)

It is strongly recommended that you clear memory on all newly installed panels before programming. Clear memory deletes all existing programming information and then resets the panel settings to their default settings. The dealer code is not erased when panel memory is cleared.

➤ **To clear panel memory:**

1. Press 8, and enter the dealer or installer code. The display shows ACCOUNT.
2. Press ▲ twice. The display shows EXIT - DL; CLEAR MEMORY.
3. Press #.
4. Enter the dealer or installer code to clear memory.

EXIT DL (1st Tier)

If Exit is selected, the panel returns to active mode. If the installer/dealer or primary code is entered, a downloader session will begin.

After all installer programming is completed, use the following procedure to exit programming mode.

➤ **To exit programming mode:**

- Press * until EXIT - DL is displayed and then press #. The current time will be displayed.

➤ **To begin a downloader session:**

- Press * until EXIT - DL is displayed and then enter installer, dealer or primary code to start a Downloader session.

User Programming Menu Items

This section guides you through the user programming menu items.

There are two tiers of user programming menus. Tier 1 menus are accessible immediately after entering the program mode.

Pressing ▼ advances forward through the menus. Pressing ▲ moves through the menus in reverse. See “Panel Keypad Button Programming Functions” on page 6 for more information on navigating through programming menus.

Entering User Programming Mode

You can enter user programming mode using the primary access code. The default primary access code is 1234.

➤ **To enter user programming mode:**

- ◆ With the system disarmed, press 8 + code. This will take you to CODES, the first menu item in Tier 1.

Codes (1st Tier)

The CODES menu lets you define security codes for the Allegro system. The CODES menu contains the following 2nd tier menus, or codes:

- MANAGER
- MAINTENANCE
- PRIMARY
- USER, 2, 3, 4

Note

This code will only be displayed in user programming if the manager code was used to enter user program mode.

MANAGER (2nd Tier)	(CODES—)
<i>(Default = none, Parameters = 4 digits, 0 to 9)</i>	
The manager code functions the same as the primary code within the user programming menu, and can arm or disarm the system.	
➤ To program/change Manager Code:	
1. Enter the manager code. The display shows CODES.	
2. Press #. The display shows MANAGER.	
3. Press # to display the current code (if any).	
4. Press #, enter the desired code and then press #.	
➤ To delete Manager Code	
◆ Press # twice. Once to delete the code and again to accept the command.	
MAINTANANCE CODE (2nd Tier)	(CODES—)
<i>(Default = none, Parameters = 4 digits, 0 to 9)</i>	
The maintenance code is to be used in conjunction with the apartment manager keychain touchpad. When a maintenance person needs access to a site protected by an Allegro, he can press disarm on the apartment manager keychain touchpad, enter the premises, then enter the maintenance code at the panel to disarm the system.	
➤ To set the Maintenance Code:	
◆ Press #, enter the desired code and then press #.	
➤ To delete Maintenance Code	
◆ Press # twice. Once to delete the code and again to accept the command.	

Note

This code will only be displayed in user programming if the manager code was used to enter user program mode.

PRIMARY (2nd Tier)	(CODES—)
<i>(Default = 1234, Parameters = 4 digits, 0 to 9)</i>	
The primary code performs all system operations and user programming.	
➤ To set the Primary Code:	
<ol style="list-style-type: none"> 1. Press # to display the current code. 2. Press #, enter the desired code and then press #. 	
USER 2, 3, 4 (2nd Tier)	(CODES—)
<i>(Default = none, Parameters = 4 digits, 0 to 9)</i>	
User Codes performs arming and disarming functions. The user codes cannot directly bypass sensors or program the primary code. The system allows up to 3 user codes (user 2 - 4).	
➤ To program/change User 2, 3, 4 Code:	
<ol style="list-style-type: none"> 1. Press # to display the current user code (if any). 2. Press #, enter the desired user code and then press #. 	
➤ To delete User 2, 3, 4 Code	
◆ Press # twice. Once to delete the code and again to accept the command.	

TIME (1st Tier)	(TIME—)
<i>(Default = 12:00 am, Parameters = 12:00 am to 11:59 pm)</i>	
This setting lets you adjust the panel's clock to the correct time. The panel uses a 12-hour clock.	
➤ To set the time:	
<ol style="list-style-type: none"> 1. Press # to display the time. 2. Enter the current time using numbered keys. 3. Use the arrow keys to select AM or PM. 4. Press #. 	

PHONE TEST (1st Tier)	(PHONE TEST—)
This setting lets you perform a manual phone test to check the phone communication between the panel and the central monitoring station.	
➤ To perform a phone test:	
◆ Press # to initiate a phone test. The panel will indicate if the test was successful or not.	

Note
The DTIM and phone number must be programmed before the panel will display the Phone Test option.

Note

While the Sensor Test is a valuable installation and service tool, it only tests sensor operation for the current conditions. You should perform a sensor test after any change in environment, equipment, or programming.

<i>SENSOR TEST (1st Tier)</i>	<i>(SENSOR TEST—)</i>
<p>This setting lets you perform a manual sensor test to check that all the sensors are working properly.</p> <ul style="list-style-type: none"> • A DTIM and panel battery test are performed at the start of the sensor test. The panel will display PHONE MODULE and beep once for every received transmission. • The panel will beep indicating the number of transmissions received, (see Table 8: “Sensor “Tripping” Instructions,” on page 28), and displays <SENSOR NAME> + OK to indicate the sensor has been tested. For the first 10 to 20 seconds of test, the volume is set to a lower level. • Panel will automatically leave sensor test after 15 minutes. Warning beeps will sound the last minute. • The panel will display TEST DONE when all sensors have been tested. <p>➤ To run a sensor test:</p> <ol style="list-style-type: none"> 1. Press # to display the sensor test (TEST; ZONE XX). The display then scrolls through the untested zones, and beeps indicating the number of sensor packets received. 2. See “Testing Sensors/Zones” on page 28 for complete sensor testing information. 3. To trip a sensor, follow the instructions in Table 8. 4. To restart the list, press 1. This will also restart the 15 minute timer. 	

<i>VOLUME (1st Tier)</i>	<i>(VOLUME—)</i>
<p><i>(Default = 0, Parameters = 0-5)</i></p> <p>This setting allows the user to adjust the panel’s status, auxiliary alarm, and arming level beep volume. The volume can be set from 0 to 5, with 0 being the lowest volume.</p> <p>➤ To set the Volume:</p> <ol style="list-style-type: none"> 1. Press # to display the current volume. 2. Press #, enter the desired volume level and then press #. 	

Version (1st tier)

The VERSION menu allows you to check the software version of the panel and phone module (DTIM) by using the following 2nd tier menus.

<i>PANEL (2nd Tier)</i>	<i>(VERSION—)</i>
<p>This setting allows the user to display the panel software, hardware and EEPROM version installed.</p> <p>➤ To display the Panel version:</p> <ul style="list-style-type: none"> ◆ Press # to display the current panel software, hardware and EEPROM version. 	
<i>PHONE MODULE (2nd Tier)</i>	<i>(VERSION—)</i>
<p>This setting allows the user to display the DTIM software, hardware and EEPROM version installed.</p> <p>➤ To display the Phone Module version:</p> <ul style="list-style-type: none"> ◆ Press # to display the current phone module software, hardware and EEPROM version. 	

Exiting User Programming Mode

After all user programming is completed, use the following procedure to exit programming mode.

- **To exit programming mode:**
- ◆ Press * until EXIT is displayed and then press #. The current time will be displayed.

Downloader Programming

Note

A Downloader Phone Number and DL Code must be programmed for remote downloader programming to work.

Downloader programming has not been investigated by UL.

Note

Downloading to an Allegro panel with software version 1.3 using ToolBox version 5.7 will turn the Smoke Verify and Loud KTP Beeps off.

The panel can be programmed remotely using ToolBox. Allegro has a 100 event buffer that can only be viewed by ToolBox. Use the information you recorded in Appendix B to inform the downloading operator of the programming requirements for this system.

ToolBox Downloader Programming

➤ To initiate a ToolBox download session:

1. Contact your downloader station and ask the operator to prepare to download to the panel.
2. Make sure the system is disarmed.
3. Go into installer program mode.
4. Press * to go to the EXIT - DL display.
5. Enter the installer, dealer, or primary code.
6. When the downloader session completes, a panel programmed status message will be displayed.

If the panel display does not flash DOWNLOAD ON, call the downloader operator to verify the downloader phone number. Also, make sure ToolBox is set up properly. Refer to “Appendix A: Troubleshooting” on page 30 if the problem persists.

➤ To initiate a ToolBox download session from off-site (10 ring method):

For off-site access where an answering machine does not exist, the user or ToolBox operator simply calls the panel location once and listens for 10 rings. The panel should answer after the tenth ring.

➤ For off-site access where an answering machine exists, the user or ToolBox operator must perform the following steps (ring/hang/ring method):

1. Call the panel location.
2. Let the phone ring once, then hang up.

Wait at least 10 seconds but not more than 40, then call the panel location again. The panel should answer on the first ring.

Testing the System

Note

UL Listed systems must be tested weekly.

You should test the system after installing, servicing, and after adding or removing devices from the system (see “Testing Sensors/Zones” on page 28).

Refer to “Appendix A: Troubleshooting” on page 30 if correct test results are not achieved.

Basic System Commands

Table 7 describes the system’s basic panel keypad operating commands. For complete details on system operation, including user programming, refer to the system’s owner’s manual.

Table 7: Basic Panel Operating Commands























How to...	Command
Check system status	 Press once
Arms doors and windows	 + Code
Arms doors and windows, no delay	 + Code + 
Arms motions, doors, and windows	 (twice) + Code
Arms motions, doors, and windows, no delay	 (twice) + Code + 
Arms doors and windows	 Press once if quick arm is on
Arms motions, doors, and windows	 Press twice if quick arm is on

Table 7: Basic Panel Operating Commands (Continued)

How to...	Command
Arms system silently	 +  + Code
Turns chime feature on and off (only when system is unarmed)	 Press once
Identifies alarms in memory	 Press once
Bypass	 + Primary Code
Disarm	 + Code
Quick Exit	 Press once, starts a 2 minute timer for use of one entry/exit door.
Police Panic	 +  Press and hold both buttons until panel indicates alarm.
Emergency Panic	 +  Press and hold both buttons until panel indicates alarm.
Fire Panic	 +  Press and hold both buttons until panel indicates alarm.

Testing Sensors/Zones

We recommend that you test sensors/zones after all programming is completed and whenever a sensor/zone-related problem occurs. See “SENSOR TEST (1st Tier)” on page 26 for complete sensor test information.

If the system does not respond as described in Table 8, see “Appendix A: Troubleshooting” on page 30.

Table 8: Sensor “Tripping” Instructions

Sensor	Do This	Number of Beeps
DTIM	Initiate a sensor test.	7-8
Door/Window	Open the secured door or window	7-8
Carbon Monoxide Alarm	Unplug the CO Alarm. Plug it back in, wait 10 seconds then press the TEST/RESET button until the unit beeps 8 times	7-8
Glass Guard	Tap the glass 3 or 4 inches from the sensor	7-8
Motion Sensor	Avoid the Motion Sensor field of view for 5 minutes, then enter its view	7-8
Rate-of-Rise Heat Detector	Rub your hands together until warm, then place one hand on the detector for 30 seconds	7-8
Shock	Tap the glass twice, away from the sensor. Wait at least 30 seconds before testing again	7-8
Smoke	Press and hold the test button until the system sounds transmission beeps	7-8
Panic Buttons	Press and hold the appropriate panic button(s) for 3 seconds	7-8
KeyChain Touchpad	Press and hold LOCK and UNLOCK simultaneously for 3 seconds	7-8
Remote Handheld Touchpad	Press and hold the 2 EMERGENCY buttons simultaneously for 3 seconds	7-8
Hardwire Loops	Open the secured door or window.	1

Table 8: Sensor “Tripping” Instructions

Sensor	Do This	Number of Beeps
Freeze	Apply ice to the sensor. Do not allow the sensor to get wet.	7-8
Water	Press a wet rag or wet finger over both of the round, gold-plated terminals on the underside of the sensor.	7-8
Dialog QS1000 Allegro Remote Station	Open the sensor connected to the touchpad’s hardwire loop or press the police panic buttons.	7-8

If a Wireless Sensor Does Not Test

When possible, locate wireless sensors within 100 feet of the panel. While a transmitter may have a range of 500 feet or more out in the open, the environment at the installation site can have a significant effect on transmitter range. Refer to “Appendix A: Troubleshooting” on page 30 to resolve the problem.

For wireless sensors that don’t respond, use an RF Sniffer (60-401) test tool to verify that the sensor is transmitting. Constant beeps from the RF Sniffer indicate a runaway (faulty) sensor. Remove the sensor’s battery and replace the sensor.

Testing Phone Communication

Perform a phone test to check the phone communication between the panel and the central monitoring station. See “PHONE TEST (1st Tier)” on page 25.


Testing Central Station Communication

After performing sensor and phone tests, check that the system is reporting alarms successfully to the central station.

➤ To test communication with the central station:

1. To avoid the dispatch of emergency personnel, call the central station and tell the operator that you will be testing the system!
2. Arm the system.
3. Test each of the panel keypad and wireless panic buttons and trip at least one sensor of each type (fire, intrusion, etc.) to verify correct operation.
4. Call central station to verify all alarms were reported.

Appendix A: Troubleshooting

Feature	Problem	Action/Solution
Panel Power		
	Panel does not power up and does not display or respond.	<ol style="list-style-type: none"> 1. Check that panel is plugged into an unswitched outlet. 2. Check the AC circuit breaker to be sure the circuit is live. 3. Check that the backup battery is installed correctly and the AC power transformer is plugged in. 4. Check for proper panel and transformer wiring. 5. Measure the incoming AC voltage at panel terminals 1 and 2. It should read between 8.0 and 12.0 VAC.
	No incoming AC voltage at panel terminals 1 and 2.	<ol style="list-style-type: none"> 1. Unplug the AC power transformer and disconnect the wires from the transformer and the panel. 2. Check transformer to panel wire for short or open circuits. 3. Plug in the transformer and check for 8.0 - 12.0 VAC at the transformer unconnected terminals. If zero (0) volts, replace the transformer. If transformer is good, call Tech Support.
	Panel display indicates <i>Low CPU Battery</i> .	<p>Note During initial installation or when the AC power was out for an extended period of time, the battery may not be fully charged yet. The battery may take up to 24 hours to charge.</p> <ol style="list-style-type: none"> 1. Perform a battery test by entering and exiting sensor test. 2. Check that the backup battery is installed correctly and the AC power transformer is plugged in. 3. Measure the incoming AC voltage at the panel terminals 1 and 2. It should read between 8.0 and 12.0 VAC. 4. Remove the backup battery power by disconnecting the battery and replace the battery. <p>Note If AC power is present, the battery voltage is only monitored during a backup battery test. The panel automatically runs a two minute backup battery test under the following conditions: (1) during user sensor test, (2) once every 4 hours, (3) when the back cover is closed. In order for the panel to update the battery status, a backup battery test must be run. (4) Power up.</p> <p>Note With the AC power transformer plugged in, the panel automatically charges the battery. While the battery is charging for the first time it is normal for the system to indicate Low CPU Battery. Charging the battery can take a number of hours depending on the battery's initial charge. Once the battery reaches 4.8 VDC (full charge as measured while in battery test), the condition clears. If the trouble condition persists after 24 hours, replace the backup battery. A Low Battery report to the central station will not be made for the first 24 hours after power up.</p>
	After pressing STATUS the panel flashes <i>AC Fail</i> , (panel continues to operate from backup battery).	<ol style="list-style-type: none"> 1. Check the AC circuit breaker to be sure the circuit is live. 2. Check for proper panel and transformer wiring. 3. Check that the transformer is supplying AC to the panel. 4. Check that the transformer is plugged into a nonswitched outlet and secured with the provided screw. <div style="display: flex; align-items: center;">  <div style="margin-left: 10px;"> <p>Warning</p> <p>Be careful when securing the transformer to an outlet with a metal cover. Hold the cover tightly in place. You could receive a serious shock if the metal outlet cover drops onto the prongs of the plug while you are securing the transformer and cover to the outlet box. If the panel does not display anything, immediately unplug the transformer and disconnect the backup battery.</p> </div> </div>
Access Code		
	Customer cannot remember access code(s).	

Feature	Problem	Action/Solution
		<ol style="list-style-type: none"> 1. Check your records to see if you have the customer's access code(s) on file. 2. Verify the access code(s) using the Downloader. 3. Use Apartment Manager code to enter user program mode and view the primary and user codes. 4. Clear memory and reprogram the panel locally.
Access Code (Continued)		
	Installer cannot remember install code.	<ol style="list-style-type: none"> 1. Check your records to see if you have the install code on file. 2. Verify the install code using the Downloader. 3. Use the Dealer Code to enter program mode and view the installer code.
Arming/Disarming		
	System protests and will not arm immediately.	<ol style="list-style-type: none"> 1. Press STATUS for an indication of the problem. 2. Make sure all monitored perimeter doors and windows are closed. 3. Make sure all perimeter and interior sensors are closed.
Bypassing		
	Sensor to bypass is not listed.	<ol style="list-style-type: none"> 1. Attempting to bypass a 24-hour sensor (a sensor that is active in all levels) that cannot be bypassed. 2. Sensor is not active in the current arming level. 3. Sensor is not learned in.
Wireless Sensor/Touchpad Battery		
	System indicates <i>Sensor/Touchpad low battery</i> .	<p>To avoid a false alarm, initiate a sensor test and then replace the indicated device battery. After replacing the battery, perform another sensor test to test the sensor/touchpad.</p> <p>Note <i>If the sensor/touchpad is not tested after battery replacement, the system continues to show a low battery condition, since that was the last signal it received from the device. Testing the sensor/touchpad with new batteries allows the panel to receive a signal with good battery information.</i></p>
Central Station Reporting		
	Central station is not receiving reports.	<ol style="list-style-type: none"> 1. Check that the premises phone line is working. 2. Perform a phone test. 3. Check for correct phone line wiring between the DTIM and RJ-31X Jack (see DTIM Installation Instructions). 4. Verify that central station phone number is programmed into the panel. If necessary, reprogram the phone number and retest. 5. Verify that the correct phone format (SIA or CID) is being used. 6. Perform a sensor test to test panel and DTIM communication.
Hardwire Zone		
	System doesn't go into alarm when zone is tripped.	<ol style="list-style-type: none"> 1. Sensor is not active in current arming level. Verify sensor group and retest. 2. Zone is not learned into panel memory. Enter installer program mode. Go to Devices, then Add and learn zone into memory. 3. Verify wiring.
	System indicates trouble and open.	

Feature	Problem	Action/Solution
		<ol style="list-style-type: none"> 1. For a normally closed contact, verify the 2 k Ohm EOL resistor is installed and a short circuit does not exist between ZCOM and ZONE. 2. For a normally open contact, verify the 2 k Ohm EOL resistor is installed and there is not an opening between ZCOM and ZONE. 3. For a normally open contact that is open, the contact has not been enrolled correctly. Delete and enroll it again.
	System indicates zone is open.	<ol style="list-style-type: none"> 1. Close the contact. 2. With the sensor closed the voltage between ZONE and ZCOM should be between 2.0 and 3.0 VDC. If this voltage is not measured, verify the 2 k Ohm EOL resistor is installed and verify wiring. 3. Verify the hardwire contact/sensor is operating properly.
Wireless Sensor Zone		
	Panel indicates sensor open condition.	<ul style="list-style-type: none"> • The sensor is open. Close the sensor to clear condition. • The magnet may be too far from the reed switch or the sensor is not installed properly. • If using external contact, the sensor may have been enrolled incorrectly. Delete and enroll the sensor following instructions.
	System doesn't respond (in sensor test or when armed) when sensor is tripped.	<ol style="list-style-type: none"> 1. Check that the wireless sensor battery is installed. 2. Check the sensor battery for low voltage. Replace batteries, if necessary. 3. Use an RF Sniffer (60-401) to verify that sensor is transmitting. 4. Constant beeps from the RF Sniffer indicate a runaway (faulty) sensor. Remove the sensor's battery and replace the sensor. 5. Sensor is not learned into panel memory. Enter installer program mode—Devices, Add, and learn sensor into memory (maximum zones = 20). 6. Sensor may be out of range. Move sensor to another location.
	Sensor reports trouble and open condition.	<ol style="list-style-type: none"> 1. Sensor tamper switch is tripped—sensor cover is off, not latched securely, spring is missing, or sensor is not mounted securely. Secure sensor mounting and/or cover, then trip sensor to clear the condition. 2. Check the sensor battery for low voltage. Replace batteries, if necessary.
	Panel indicates sensor trouble condition.	<ol style="list-style-type: none"> 1. The sensor has reached its supervisory limit. Use an RF Sniffer (60-401) to verify that sensor is transmitting. If sensor is not transmitting, check battery for low or no voltage and replace. 2. Change mounting position of sensor (from horizontal to vertical or vice versa) and test sensor several times for consistency. 3. Sensor signal is not reaching panel/receiver because sensor is too far away or there is too much interference. Remove sensor from mounted location and test from other locations. Mount sensor in area where signal can reach panel/receiver.
	Panel indicates sensor trouble and alarm	
	Smoke detector is dirty or there is a small amount of smoke in the chamber.	
	Smoke sensor beeps once every minute.	
	Sensor batteries are getting low. Replace batteries.	
	Note System Sensor smoke sensors do not transmit a low battery signal to the panel/receiver until battery voltage drops to within a range of 7.0 to 7.8 VDC. The sensor sounds beeps to notify occupants that the sensor's batteries need replacing, but the sensor does not transmit a low battery signal to the panel until the next supervisory signal (69 minutes later).	
Wireless Touchpad		
	System doesn't respond to commands entered from wireless touchpad.	

Feature	Problem	Action/Solution
		<ul style="list-style-type: none"> • Check for dead batteries. • Perform a sensor test.
	Touchpad reports trouble condition.	Check the touchpad battery for low voltage. Replace battery, if necessary.
DTIM		
	Panel displays TEL MOLDULE INITIALIZING	<p>After panel power up, the panel and the DTIM need to synchronize their communication. This could take approximately 5 minutes. To eliminate the 5 minute wait, remove and replace the DTIM cover. The message should go away within 10 seconds.</p> <ul style="list-style-type: none"> • If the panel continues to display TEL MODULE INITIALIZING, continue with the procedure for Telephone module failure.
	Telephone Module Failure	<p>The DTIM's signals may not be reaching the panel</p> <ul style="list-style-type: none"> • Using an RF Sniffer, verify the DTIM is transmitting by removing the cover. The DTIM will transmit whenever its cover is removed/replaced. <p>If the DTIM is not transmitting</p> <ol style="list-style-type: none"> 1. Check the DTIM battery for low or no voltage. Replace if necessary 2. Call technical support for assistance. <p>If the DTIM is transmitting</p> <ul style="list-style-type: none"> • Use an RF Sniffer to verify the panel is transmitting. Power down and then power up the panel. Place an RF Sniffer next to the panel's antenna (right side). You should hear beeps immediately after applying power. <p>If the panel is not transmitting.</p> <ul style="list-style-type: none"> • Contact technical support for assistance. <p>If the DTIM and the panel are transmitting.</p> <p>The DTIM's signal may not be reaching the panel because it is too far away from the panel or there is too much interference.</p> <ol style="list-style-type: none"> 1. Remove the DTIM from its mounted location and test from other locations. 2. Mount the DTIM in an area where the signal can reach the panel. If easier, the panel can also be moved. 3. To increase range, install the panel's antenna in a wall. 4. Delete and enroll the DTIM to insure proper programming.
	Panel displays PHONE MODULE LOW BATTERY.	<ol style="list-style-type: none"> 1. Replace the DTIM's battery. 2. Replace the DTIM's cover. 3. Perform a phone test to clear the low battery condition. The DTIM performs a battery test when calling out.
	Panel displays TEL MODULE MEMORY FAIL	<ul style="list-style-type: none"> • Contact technical support for assistance.
	Panel displays TELEPHONE MODULE TAMPER.	<ol style="list-style-type: none"> 1. Verify the DTIM's cover is on and latched securely. Install the cover securely to clear the condition. 2. Remove the cover and inspect the DTIM's tamper switch. The switch should have a spring installed. If the spring is missing the tamper switch will not function correctly. 3. Contact technical support for assistance if spring is missing.
	Panel displays PHONE MODULE SERVICE REQUIRED.	<p>Inconsistent communication between the panel and DTIM.</p> <ol style="list-style-type: none"> 1. Remove the DTIM from its mounted location and test from other locations. 2. Mount the DTIM in an area where the signal can reach the panel. If easier, the panel can also be moved. To increase range, install the panel's antenna in the wall. To clear the condition, cycle the panel power off and on.

Feature	Problem	Action/Solution
	Panel displays TEL MODULE VERSION ERROR.	The DTIM software or EEPROM may not be compatible with the panel software. 1. Contact technical support for assistance.
Phone		
	Constant dial tone, preventing dial-out on premises phones.	One or more polarity-sensitive phones exist on-site.
	Panel displays <i>phone 1 fail, phone 2 fail, or phone failure</i> .	1. Check DTIM wiring (see DTIM installation instructions). 2. There may be a problem with the central station.
Phone Test		
	Panel does not display option to perform a phone test.	<ul style="list-style-type: none"> • The central station phone number is not programmed in. • DTIM has not been enrolled. • Phone test option is off.
	Alarm report is not called into central station.	<ol style="list-style-type: none"> 1. Perform a phone test. 2. Check to make sure the phone test option is on. 3. Verify that high and/or low level reporting option is on. 4. Perform a sensor test to verify communication between the DTIM and panel. See "Phone Test (2nd Tier)" on 25
Downloader		
	Download/upload session fails on a pre-programmed panel.	<ol style="list-style-type: none"> 1. Verify Downloader Phone Number matches ToolBox setting. 2. Verify Downloader CODE matches ToolBox setting. 3. Verify Dealer CODE matches ToolBox setting. 4. Verify panel Account Number matches ToolBox setting.
	Download/upload session fails on an unprogrammed panel.	<ol style="list-style-type: none"> 1. Verify Downloader Phone Number matches ToolBox setting. 2. Verify Downloader CODE matches ToolBox setting. 3. Verify Dealer CODE matches ToolBox setting.
Receiver		
	Panel displays RX JAM.	<p>There may be a "runaway" transmitter - a transmitter that is constantly transmitting.</p> <ol style="list-style-type: none"> 1. Use an RF Sniffer to identify the runaway transmitter. Place the RF Sniffer next to each RF sensor until you find the sensor that is transmitting. 2. Remove the battery from the sensor. 3. Replace the sensor.
	Panel displays RX FAILURE.	<p>The panel has not heard an RF signal for 4 hours.</p> <ol style="list-style-type: none"> 1. Contact technical support for assistance.

Appendix B: Reference Tables

Table B1: Sensor Group Characteristics

No.	Name	Application	Alarm	Delay	Restoral	Supervisory	CS Report	Chime	Active Levels
00	Fixed Panic	24-hour audible fixed emergency buttons.	Police	Instant		√	√		1, 2, 3
01	Portable Panic	24-hour audible portable emergency buttons.	Police	Instant			√		1, 2, 3
02	Fixed Panic	24-hour silent fixed emergency buttons.	Silent	Instant		√	√		1, 2, 3
03	Portable Panic	24-hour silent portable emergency buttons.	Silent	Instant			√		1, 2, 3
04	Fixed Emergency	24-hour emergency sensor, such as Pendant Panic or holdup button.	Emergency	Instant		√	√		1, 2, 3
06	Portable Emergency	24-hour portable emergency alert button.	Emergency	Instant			√		1, 2, 3
08	Special Intrusion	Special belongings, such as gun cabinets and wall safes.	Police	Instant	√	√	√		1, 2, 3
09	Special Intrusion	Special belongings, such as gun cabinets and wall safes.	Police	Standard	√	√	√		1, 2, 3
10	Entry/Exit Delay	Entry and exit doors that require a standard delay time.	Police	Standard	√	√	√	√	2, 3
13	Instant Perimeter	Exterior doors and windows.	Police	Instant	√	√	√	√	2, 3
14	Instant Interior	Interior doors.	Police	Follower	√	√	√		2, 3
15	Instant Interior	Interior PIR motion sensors. *	Police	Follower		√	√		2, 3
16	Instant Interior	Interior doors.	Police	Follower	√	√	√		3
17	Instant Interior	PIR motion sensors. *	Police	Follower		√	√		3
18	Instant Interior	PIR motion sensors subject to false alarms. (Cross-Zone) * †	Police	Follower		√	√		3
19	Delayed Interior	Interior doors that initiate a delay before going into alarm. *	Police	Standard	√	√	√		3
20	Delayed Interior	PIR motion sensors that initiate a delay before going into alarm. *	Police	Standard		√	√		3
21	Local Instant Interior	24-hour local alarm zone protecting anything that opens and closes.	Police	Instant	√	√			1, 2, 3
22	Local Delayed Interior	Same as group 21, plus activation initiates a delay before going into alarm.	Police	Standard	√	√			1, 2, 3
23	Local Instant Emergency	24-hour local alarm zone protecting anything that opens and closes. ‡	Emergency	Instant	√	√			1, 2, 3
25	Local Special Chime	Notify the user when a door is opened. Sounds emit from a local annunciator. * If using a PIR motion sensor, use only Part No. 60-511-01-95.	Special Chime	Instant		√			1, 2, 3
26	Fire	24-hour fire, rate-of-rise heat, and smoke sensors.	Fire	Instant	√	√	√		1, 2, 3
29	Freeze	Freeze Sensors	Emergency	Instant	√	√	√		1, 2, 3

Table B1: Sensor Group Characteristics (Continued)

No.	Name	Application	Alarm	Delay	Restoral	Supervisory	CS Report	Chime	Active Levels
33	Siren	Siren Supervision	Silent	Instant		√	√		1, 2, 3
34	Gas	Carbonmonoxide (CO) Gas Detectors ‡	Emergency	Instant	√	√	√		1, 2, 3
38	Water	Water Sensors	Trouble Beeps	Instant	√	√	√		1, 2, 3
39	DTIM	Dialog Telephone Interface Module (DTIM) ⌘	Police	Instant		√	√		

Check marks (√) represent characteristics present in a group.
 * This group is not certified as a primary protection circuit for UL-listed systems and is for supplementary use only.
 † Sounds an instant local alarm if one sensor is tripped. Sounds police siren if two or more sensors are tripped within 4 minutes. Otherwise sensors are followers to delayed sensors. If Alarm Verification is on, group 18 functions like group 17.
 ‡ This group has not been investigated by UL.
 ⌘ The DTIM will report in all levels.
 Siren Type:
 Police - A high level steady siren.
 Fire - A high level temporal siren.
 Silent -No siren.
 Emergency - A low level on-off patterned siren.
 Delay:
 Instant -A sensor of this type will cause an immediate alarm if a violation occurs anytime in an active arming level.
 Standard - A sensor of this type will cause an entry delay if a violation occurs anytime in active arming level. A violation during an exit delay will not cause an alarm.
 If the arming level modifier No Delay is enabled a sensor of this type will cause an immediate alarm if the violation occurs during an active arming level.
 Follower - A sensor of this type will cause an immediate alarm if a violation occurs during an active level unless an entry or exit delay is in progress. If violated during an entry delay and the entry delay expires the sensor will go into alarm.

Cross-Zoning

Note
 Cross-zoning is not recommended for exit/entry zones. Each zone has the ability to individually protect the intended area (e.g. motion detector patterns overlap).

Cross-zoning or two-trip refers to two different Group 18 sensors that must be tripped within four minutes of each other in order for an alarm to be sent. The diagram in Figure 7 shows the path of a person walking from the kitchen to the living room. When the person is detected walking through the kitchen, the motion sensor in the kitchen is tripped, sounding a local alarm. If motion is detected by the living room motion sensor within 4 minutes an alarm report will be sent to the central station.




Figure 7. Cross-Zoning

Table B2: System Settings

Menu Name	Default	Parameters	Settings
Account	00-000	4-10 digits; 0-9, A-F	
Number 1	none	24 digits; 0-9, *, #, pause	
FMT - CID/SIA	CID	On=CID, Off=SIA	
High LVL	On	off, on	
Low LVL	On	off, on	
Openings	Off	off, on	
Closings	Off	off, on	
Number 2	none	24 digits; 0-9, *, #, pause	
FMT - CID	CID	On=CID, Off=SIA	
High LVL	Off	off, on	
Low LVL	Off	off, on	
Openings	Off	off, on	
Closings	Off	off, on	
Backup	On	off, on	
Dial DLY	30	15-45	
Pre-dial String	none	8 digits; 0-9, *, #, pause	
DTMF Dial	On	off, on	
Number	none	24 digits; 0-9, *, #, pause	
DL Code	12345	5 digit code, 0-9	
Install Code	4321	4 digit code, 0-9	
Dealer Code	none	4 digit code, 0-9	
Duress Code	none	4 digit code, 0-9	
Manager Code	none	4 digit code, 0-9	
Maintenance Code	none	4 digit code, 0-9	
Entry DLY	30 (45 for UL)	30-240	
Exit DLY	60 (60 for UL)	45-254	
Auto Phone Test	0 (Off)(1 for UL)	0-255	
Quiet Time	On (Off for UL)	off, on	
Quiet Hour	22	0-23	
Rearm Timer	0	0-12	
KTP Arm	Off	off (ratchet arm), on (all on), No Delay	
Police Panic	On	off, on	
Emergency Panic	Off	off, on	
Fire Panic	On	off, on	
Rcvr Trouble	Off (On for UL)	off, on	
Panel Tamper	On	off, on	
Exit EXT	On (Off for UL)	off, on	

Table B2: System Settings (Continued)

Menu Name	Default	Parameters	Settings
Swinger Shutdown	1	1-2	
Quick Arm	Off	off, on	
Quick Exit	On (Off for UL)	off, on	
Auto Stay Arm	On	off, on	
Supv Time	Random between 1AM and 3:59AM	12 AM - 11:59 PM	
Alarm Verify	Off (Off for UL)	off, on	
Smoke Verify	Off	off, on	
Demo Kit	Off	off, on	
AC Fail	Off (On for UL 1635)	off, on	
Low CPU Battery	On (On for UL 1635)	off, on	
Phone Test	On	off, on	
Fire Restoral	Off	off, on	
Siren Time Out	4 (Min for UL)	1-30	
Trouble Beeps	On (On for UL)	off, on	
Alarm Volume	6 (Min for UL)	0-6	
Loud KTP Beeps	Off	off, on	

Table B3: Sensor Information

Sensor Number	Sensor Text	Sensor Type	Sensor Group
01			
02			
03			
04			
05			
06			
07			
08			
09			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			

Appendix C: Installation Menus

Account
 4-10 digits 00000

Phones

# → Phone 1	# → Number 1
← * 15-45	← * 24-digits none
▲	▲
# → Phone 2	# → Number 2
← * 15-45	← * 24-digits none
▲	▲
# → Dial Dly	# → FMT-CID
← * 15-45	← * CID SIA
▲	▲
# → Pre-Dial String	# → High Lvl
← * 8-digits none	← * On Off
▲	▲
# → DTMF Dial	# → Low Lvl
← * On Off	← * On Off
▲	▲
	# → Openings
	← * On Off
	▲
	# → Closings
	← * On Off
	▲
	# → Backup
	← * On Off

Devices

→ Add
← *
▲
→ Delete
← *
▲
→ Review
← *
▲
→ Text
← *

Downloader

→ Number
← * 24-digits none
▲
→ DL Code
← * 5-digits 12345

Codes

→ Install Code
← * 4-digits 4321
▲
→ Dealer Code
← * 4-digits none
▲
→ Duress Code
← * 4-digits none
▲
→ Manager Code
← * 4-digits none
▲
→ Maint. Code
← * 4-digits none

Timers

→ Entry Dly
← * 30-240 30 Sec
▲
→ Exit Dly
← * 30-254 60 Sec
▲
→ Auto Phn Test
← * 0-255 0 (Off)
▲
→ Quiet Time
← * On Off
▲
→ Quiet Hour
← * 0-23 22
▲
→ Rearm Timer
← * 0-12 0

Options

→ KTP Arm
← * On Off
▲
→ Police Panic
← * On Off
▲
→ Emergency Panic
← * On Off
▲
→ Fire Panic
← * On Off
▲
→ Rcvr Trouble
← * On Off
▲
→ Panel Tamper
← * On Off
▲
→ Exit Ext
← * On Off
▲
→ Swinger Shutdown
← * 1 2
▲
→ Quick Arm
← * On Off
▲
→ Quick Exit
← * On Off
▲
→ Auto Stay Arm
← * On Off
▲
→ Supv Time
← * Random Time
▲
→ Alarm Verify
← * On Off
▲
→ Smoke Verify
← * On Off
▲
→ Demo Kit
← * On Off

Reports

→ AC Fail
← * On Off
▲
→ Low CPU Battery
← * On Off
▲
→ Phone Test
← * On Off
▲
→ Fire Restoral
← * On Off

Siren

→ Siren Time Out
← * 1-30 4 min
▲
→ Trouble Beeps
← * On Off
▲
→ Alarm Volume
← * 0-6 6
▲
→ Loud KTP Beeps
← * On Off

Clear Memory

Exit - DL

Tier 1 Menu

Tier 2 Menu
 Range Default

Tier 3 Menu
 Range Default

▼▲ Press the arrow keys to scroll through menus.
 # Press the Pound key to select a menu item or enter data.
 * Press the asterisk key to deselect a menu item or entry.

**Appendix D:
Software
Release Notes**

Allegro Software Version 1.3

The following features were changed or added for software version 1.3.

Dialog QS1000 Allegro Remote Station

Added support for the Dialog QS1000 Allegro Remote Station.

Loud KTP Beeps

Added programming option Loud KTP Beeps. See “LOUD KTP BEEPS (2nd Tier)” on page 23.

Smoke Verify

Added programming option Smoke Verify. See “SMOKE VERIFY (2nd Tier)” on page 20.

Dial Delay

Changed maximum value from 120 to 45. See “DIAL DLY (2nd Tier)” on page 11.

SAW Sensors

Added support for the SAW Water and Freeze Sensors. Added sensor group 29 for the Freeze Sensor and sensor group 38 for the Water Sensor. See “Sensor Group Characteristics” on page 35.

Crystal Sensors

Added support for the Crystal Freeze sensor. Added sensor group 29 for the Freeze Sensor. See “Sensor Group Characteristics” on page 35.

Force Arm Reporting

Changed Force Arm reporting. The panel now reports all the sensors that are bypassed during a forced arming.

Exit Delay

Changed minimum Exit Delay time from 45 to 30 seconds.

Fire Restoral

Added programming option Fire Restoral. See “FIRE RESTORAL (2nd Tier)” on page 22.

Specifications

Model No.:	60-874-95R
Power Requirements:	8 or 9 VAC, minimum 300 mA Must be a GE Security recommended transformer.
Backup Battery:	4.8 VDC rechargeable NiCd battery pack
Estimated Battery Life:	Provides 24-hours of operation without AC Power
RF Frequency:	319.5 MHz + or - 140 kHz
Nominal Range:	500 feet, (150 m) open-air receiving range
Operating Temp Range:	32° to 122° F (0° to 49° C)
Storage Temp Range:	-30° to 140° F (-34° to 60° C)
Relative Humidity:	5-90% non-condensing
Dimensions (in):	7.5 x 6.75 x 1.5 (L x W x D)
Weight (lb):	1.0
Installation:	On wall mounting
Zones:	20 total, including 1 hardwire and 1 for DTIM