

INSTRUCTION MANUAL

Date and Time Instructions

GE Concord Express



Setting the Date and Time

Program Time

- 1) Press the menu button on the key pad (9)
- 2) Enter the master code (default is 1234)
- 3) The display should show Time-Date
- 4) Press the # button (the display shows the programmed time)
- 5) Enter the desired time in 24 hour format (00:00 ex 13:01 is 1:01pm) press # to set
- 6) Press * button until display shows Time-Date
- 7) Press the A or B button until the display shows end program
- 8) Press the # button

Program Date

- 1) Press the menu button on the key pad (9)
- 2) Enter the master code (default is 1234)

- 3) The display should show Time-Date
- 4) Press the # button
- 5) Press the A or B button until the display shows the programmed date
- 6) Enter the desired date (mm/dd/yy ex 01/30/08 is January 30th 2008) press # to set
- 7) Press * button until display shows Time-Date
- 8) Press the A or B button until the display shows end program
- 9) Press the # button