

# INSTRUCTION MANUAL

## Date and Time Instructions

# GE Concord 4



# *Setting the Date and Time*

## Time Programming (System Clock)

1. Press 9 + Master CODE.
2. Press 020
3. Enter the correct time in 24-hour format. Press #.
4. Press \* + 00 + # to exit.

## Date Programming (System Date)

1. Press 9 + Master CODE.
2. Press 021.
3. Enter the current date as six digits (mm/dd/yy).  
Press #.
4. Press \* + 00 + # to exit.