

INSTRUCTION MANUAL

Date and Time  
Instructions

*Power series*  
*PC 3000*



## *Setting the Date and Time*

Step 1 – Enter time programming by pressing [\*][6] + [Master Code] + [1]

Step 2 – Enter [HH:MM]

Step 3 – Press [#] to exit

Note: You can also program the time using military standard (e.g. 8:00 pm = 20:00 hours)